

## MODEL: R5K SINGLE ENHANCED PATIENT STATION AUDIO



R5KPS1EA



### FEATURES

- Provides voice communication to resident bedside with entertainment muting during nurse call
- DIN receptacle for resident nurse call and entertainment controls
- Single point output for lighting control
- Monitor LED and Call Assurance LED
- Annunciates cord-out
- Interfaces with specialty beds via optional module
- Cancel button for station or room-wide cancel function
- Optional antimicrobial Bio-seal to cover Cancel button
- Continuous supervision for station presence
- Surface mount for easy installation
- Mounting design accommodates a variety of single and dual gang backboxes

### SPECIFICATIONS

**Power Requirements:** 15.5V DC @ 11 mA

**Weight:** 154 g (5.4 oz)

**Size: W:** 11.97 cm (4.71")

**H:** 10.96 cm (4.31")

**D:** 2.38 cm (0.94")

**Housing and Finish:** Polycarbonate ABS, UL 94-5VA; light gray faceplate.

**Controls/Indicators:** One (1) DIN receptacle, One (1) Call Assurance LED, One (1) Monitor LED, and One (1) Cancel button.

### DESCRIPTION

The R5KPS1EA is an enhanced single bed station that provides voice communication to the nurse call system. It allows both residents and staff to place different call-in priorities to the assigned console(s). Entertainment audio through the pillow speaker is muted during nurse call. The bed station can interface with call cords and entertainment speakers to initiate calls, provide entertainment control, and allow intercom communication to the console over the station speaker. The station also provides an interface to a single lighting control module.

With the addition of the R4KFB1 Feature Bed Interface

**Backbox Requirement:** Surface mountable; compatible with European, North American, South American single and dual gang boxes.

**Terminations:** Plug on connector, CAT 5 and CAT 6 compatible

**Certifications:** Designed for compliance to ANSI/UL 1069, IEC 60950, CE, RoHS / WEEE Compliant. Assembled in a U.S. FDA Registered facility.

module, the station will provide nurse call and entertainment audio at the feature bed and pillow speaker.

The bed station is connected to its associated corridor light or domeless controller and is continuously supervised for station presence. If the call cord is removed from the station, a Cord Out call is immediately annunciated on the covering console(s). In addition, a "Trouble" message will also annunciate at the covering console(s) if the station is removed from the system or becomes non-functional.



**Rauland**  
 A Division of AMETEK, Inc.  
[www.Rauland.com](http://www.Rauland.com)

Toll Free +1 800 752 7725  
 From Outside the U.S. +1 847 590 7100

*Architect and Engineer (A&E) Specifications available online at [customerconnection.rauland.com](http://customerconnection.rauland.com)  
 Specifications subject to change without notice.*